

# Quick Guide


# MLS Magic 10.1"



**MAIC**  
MLS Artificial Intelligence Center

## Activate - Start

To activate your device, press and hold the activation key (No. 7 in the following page) You can chose between the operating systems Android 5.1 and Windows 10 in the first screen that will appear.



Your initial choice during activation is not binding, you can switch from one operating system to the other whenever you want.

## Operation

The device can be used in two ways. As a laptop (with a touch screen) and also as a tablet.  
Its charging is done through the tablet-screen.

## Structure






### Πληκτρολόγιο

- ① MicroSD card port
- ② USB 3.0 port
- ③ Micro USB port
- ④ USB 2.0 port
- ⑤ Micro HDMI port
- ⑥ 3.5mm earphone socket
- ⑦ Activation key / lock
- ⑧ Increase/ Decrease volume key
- ⑨ Front camera
- ⑩ Rear camera
- ⑪ Tablet-keyboard connection
- ⑫ Caps Lock indication Device
- ⑬ Device operation indication
- ⑭ Touchpad
- ⑮ Start Menu (windows)

## Android environment




At the initial Android screen, touch any icon to access the relative application.

To move back to the home screen, tap on the  home screen icon. To move back , tap on the back icon  . To open the active application management screen, touch the tab  .

## Switching from Android to Windows

To switch from the Android environment to the Windows one, press and hold the activation/deactivation key and touch one of the first option that will appear "Restart in Windows".




## Main menu

Navigate on the main menu by dragging the screen left and right to switch pages on the main menu. Tap and hold on any icon you want, in order to drag it to the main screen, as a shortcut. To go back to the main screen press the corresponding key.

## Lock & Unlock

In order to lock your device, tap the activation key. In order to unlock your device, tap the activation key. When the lock icon appears on the screen, drag upwards.

## Settings

To access all settings options, touch the top of the touch screen and drag downwards twice. By tapping on the following key  you can access the general settings. On the "Settings" screen, you can personalize your device to suit your needs, by setting its functions accordingly.

Networks, WiFi, Bluetooth settings, sounds, appearance, applications, all at the tips of your fingers.

## MAIC (Settings)

You can set the basic functions of your device through MAIC. Specifically, you can activate/ deactivate the Bluetooth, wifi, data use, gps and silent mode.

Alternatively, you can just say "Settings" and then chose from the settings options

## Quick Settings

By dragging once the upper end of the screen downwards, the settings options will appear. If you drag it once more, quick settings will appear, as shown below.



**Brightness** - Sets the brightness of the screen.



**Wireless networks** - EActivate the wifi when you're inside the range of a known wireless network and deactivate it when you're moving away and you want to save battery power.



**Bluetooth** - Allow your device to connect with other devices and Bluetooth accessories to transfer contacts, photos and files or to just use your wireless earphones.



**Automatic Rotation** - It allows the automatic rotation of the screen.




**AGPS** - Activate your GPS and your MLS device will give you information regarding your geographical location in any application necessary, such as Talk&Drive.



**Flight Mode** - When you activate Flight Mode, all wireless connectivity options will be deactivated. You can reactivate the WiFi and Bluetooth applications through settings or through the quick settings menu.

Drag the notifications screen once and you can see all your notifications, i.e. Messages, missed calls, e-mails, application updates.



## Music and Videos

Transfer the music you like to your device, download music from the internet and enjoy the high quality sound from your device's speaker or your earphones. A world full of music at the tips of your fingers. A world you can create and enjoy, exactly as you prefer.

Watching videos you like is a piece of cake with your MLS device. Furthermore, it offers you video descriptions and information with mini pictures and playlist texts. Your favorite movies, series or YouTube videos can keep you high quality company, wherever you are.

## Photos and Camera

Touch, tap or pinch on the screen of your device to zoom in or zoom out on a picture. Furthermore, there's automatic rotation between horizontal and vertical function for picture screening. Your favorite moments are always with you, in the way you want to remember them.

By using zoom, you can take your favorite pictures or videos. Save party moments, concerts, vacation or any other pictures or videos you like in your device's memory and your own, or Share them with your friends through e-mail.

## Home screen

Arrange your folders, your applications and widgets by tapping and holding your finger on any icon and drag it where you wish.

Through this process, the home screen of your device will be arranged in a way that best serves your needs.


## Internet

By choosing the internet browser application on the lower right side of the home screen and by inputting the website you would like to visit, you can easily surf the web and immediately navigate on any web page you like.

Furthermore, you can touch the screen to zoom in/ zoom out and you can chose through the "Menu" to open more windows for simultaneous navigation in different internet web pages. Discover the easiest and fastest Internet trip ever.

## Windows environment

At the initial Windows screen, touch any icon to access the relative application.



**Start Menu** - Tap on the "Start" key on the taskbar. You'll find the applicationw you use more often on the left side, the list of All Applications, as well as the shortcuts to other locations on your computer, such as File Search and Settings.



**Operation** - Apart from activation/ deactivation, you can set the device on sleep mode.



**Settings** - General Windows Settings.





**All applications** - It gives you access to a list of all applications installed on the windows environment, in an alphabetical order for your easy search.




**Search Files** - Search for your files or your folders.

## Switching from Windows to Android

To switch from the Windows environment to the Android one, tap on the key  "Start Menu" on the lower left side of your screen.

Next, tap on  "Operation" and from there, "Restart" or "Shut down" and then activate your device.

The following screen will appear, and you'll be able to chose the environment you would like to switch to.



## MLS AFTER SALES SUPPORT SERVICE

You bought an MLS device? You don't know how it works?  
You don't know how to update the MLS Talk& Drive Maps?  
What's MAIC? How do I use Talk&Call? MLS is there for you to solve all your possible problems! Customer Service is here to help you and answer any questions you might have. For issues such as:

- ▶ Your device won't turn on?
- ▶ Won't charge?
- ▶ How do I update it?
- ▶ MAIC doesn't understand me. I lost all my contacts.
- ▶ MAIC, MLS Talk&Call and MLS Talk&Drive do not work &
- ▶ How do I export my contacts to my SD card?
- ▶ The storage space of my device is limited. My device has a low response rate.
- ▶ GOS doesn't work.
- ▶ The flash or the vibrating function do not work.
- ▶ My device won't connect to my computer or is not recognized by my computer
- ▶ The SD card is not recognized

Before you talk to one of our resellers, you can contact us with the following ways:

### Customer Service Call Center



Tηλ.2310 989838



Fax.2310 989808



Email: support@mls.gr

Monday to Friday 9:30am-8:30pm

Saturday 10:30am-3:30pm

### Στα MLS Stores

#### MLS Store Mall



35, Andrea Papandreou str., 15125 Marousi (inside The Mall Athens)



Tel. 210 6104859



Fax 210 6107683



Email: mlsmall@mls.gr

Monday to Friday 10:00am - 9:00pm

Saturday 10:00am - 8:00pm

#### MLS Store Piraeus



120, Grigoriou Lampraki str., 18532, Piraeus



Tel. 210 4111160



Fax: 210 4111161



Email: mlspeiraias@mls.gr

Monday/Wednesday/Saturday 9:00am-3:00pm

Tuesday/Thursday/Friday 9:00am-9:00pm

#### MLS Store Cosmos



11Th km National Road of Thessaloniki/ Nea Moudania, 570 01, Thessaloniki (inside Mediterranean Cosmos)



Tet. 2310 475263



Fax: 2310 475264



Email: mlscosmos@mls.gr

Monday to Friday 10:00am - 9:00pm

Saturday 10:00am - 8:00pm

#### MLS Store Tsimiski



119, Tsimiski str., 54621, Thessaloniki



Tel. 2310 220538



Fax 2310 220548



Email: mlstsimiski@mls.gr

Monday/Wednesday 9:00am-5:00pm

Tuesday/Thursday/Friday: 9:00am - 9:00pm

Saturday 9:00am - 9:00pm

## MLS Offices

---

### Customer Service Department of Attica

📍 40, Digeni Akrita str. & Argyroupoleos, T.K. 16451, Argyroupoli

Monday to Friday 9:00am-5:00pm

### Customer Service Department of Thessaloniki

📍 VEPE TECHNOPOLIS, 555 35, Pylaia, Thessaloniki

Monday to Friday 9:00am-5:00pm

## MLS Updater

For your accommodation, MLS has created the MLS Updater. MLS Updater is a tool that allows you to do the following to your Android device:

- ▶ Update the latest MLS Services versions.
- ▶ Update your maps
- ▶ Update your ROM software by fixing possible problems.
- ▶ Keep yourself updated on important subjects regarding
- ▶ MLS products and services

MLS Updater is pre-installed in your device. For better support, MLS suggests that you regularly update it to its latest version through Google Play Store. In that way, you'll be continuously updated and receive support for technical issues.

Note: MLS Updater is exclusively addressed to MLS smartphone and tablet users.

MLS Destinator users can update their maps to their latest version via our website [www.mls.gr](http://www.mls.gr). Register on our members tab and download the new maps for free via The process is simple and does not require advanced computer knowledge.



The information included in the manual that you're holding are indicative.

Real time functions vary, depending on the operating system edition of the device.



© 2003-2018 MLS.

All rights reserved.

The business names and logos MLS and MAIC are trademarks owned by MLS Innovation registered in Greece and in other countries.

Android™ and YouTube™ are trademarks owned by Google. In-cWindows™ is a Microsoft trademark.



0700

MLS is not responsible for possible typographical errors.