

## Quick Guide




### Structure



- ① Rear flash
- ② 3.5mm earphones slot
- ③ Micro USB slot
- ④ Rear camera
- ⑤ Receiver
- ⑥ Speaker
- ⑦ Front camera
- ⑧ Front flash
- ⑨ Increase / Decrease volume key
- ⑩ Activation key / lock
- ⑪ SD and SIM card protective cover
- ⑫ Back to the previous screen
- ⑬ Home screen key
- ⑭ Active Applications management
- ⑮ Microphone

When you switch on your phone for the first time, press key number (10) and hold to activate.

At the initial screen, touch any icon to access the relative application.

To move back to the home screen, touch the  home screen key. To move back, tap on the back icon . To open the active application management screen, touch the tab .

## Εισαγωγή κάρτας SD και SIM

Place the SIM card in the corresponding slot **1** as shown in the picture.

Place the SIM card in the corresponding slot **2** as shown in the picture.



## Telephone Assistance



© 2003-2018 MLS.  
All rights reserved.

The business names and logos MLS, MAIC and MLS Sevens 3G are trademarks owned by MLS Innovation, registered in Greece and in other countries.

Android is trademark owned by Google Inc

With the present, the manufacturer MLS Innovation declares that the device is in compliance with all essential demand and other relative clauses of the directive 1999/5/EC.

A copy of the Compliance Declaration can be found at the MLS website: <http://www.mlshop.gr/content/diloseis-symmorfosis>

