

Δομή




- | | |
|----------------------------|--------------------------------------|
| ① Θύρα Micro USB | ⑨ Πλήκτρο ενεργοποίησης /κλειδώματος |
| ② Θύρα Micro HDMI | ⑩ Πλήκτρα αυξομείωσης έντασης ήχου |
| ③ Υποδοχή ακουστικών 3.5mm | ⑪ Επιστροφή στην προηγούμενη οθόνη |
| ④ Υποδοχή Micro SD | ⑫ Πλήκτρο αρχικής οθόνης |
| ⑤ Reset | ⑬ Διαχείριση ενεργών εφαρμογών |
| ⑥ Μπροστινή Κάμερα | ⑭ Μικρόφωνο |
| ⑦ Πίσω κάμερα | |
| ⑧ Ηχείο | |

Κατά την πρώτη χρήση πατήστε παρατεταμένα το πλήκτρο 9, για να ενεργοποιήσετε τη συσκευή.

Στην αρχική οθόνη, αγγίξτε οποιοδήποτε εικονίδιο για να αποκτήσετε πρόσβαση στην αντίστοιχη λειτουργία.

Για να επιστρέψετε στην αρχική οθόνη, πατήστε το πλήκτρο ○ αρχικής οθόνης. Για να επιστρέψετε στην προηγούμενη οθόνη, αγγίξτε το πλήκτρο επιστροφής ◀. Για να εμφανίσετε την οθόνη διαχείρισης ενεργών εφαρμογών αγγίξτε το πλήκτρο □.

Τηλεφωνική εξυπηρέτηση



© 2003-2017 MLS.

Με την επιφύλαξη παντός δικαιώματος.

Η επωνυμία και τα λογότυπα MLS και MAIC είναι εμπορικά σήματα της MLS Πληροφορική, κατατεθέντα στην Ελλάδα και σε άλλες χώρες.

Το Android είναι εμπορικό σήμα της Google, Inc.

Με την παρούσα ο κατασκευαστής MLS Πληροφορική Α.Ε. δηλώνει ότι η συσκευή συμμορφώνεται προς τις ουσιώδεις απαιτήσεις και τις λοιπές σχετικές διατάξεις της οδηγίας 1999/5/ΕΚ.

Αντίγραφο της Δήλωσης Συμμόρφωσης μπορεί να αποκτηθεί από τον δικτυακό τόπο της MLS: <http://www.mlsshop.gr/content/diloseis-symmorfosis>

MLS Innovation Inc. ICT Business Park, 555 35, Θεσσαλονίκη, Ελλάδα
www.mls.gr, mail@mls.gr






Structure



- | | |
|------------------------|---------------------------------|
| ① Micro USB Slot | ⑧ Speaker |
| ② Micro HDMI Slot | ⑨ Activation Key/Lock Key |
| ③ Headphone Jack 3.5mm | ⑩ Volume-shifting keys |
| ④ Card slot drawer SD | ⑪ Previous screen |
| ⑤ Reset | ⑫ Home screen |
| ⑥ Front Camera | ⑬ Screen of active applications |
| ⑦ Main Camera | ⑭ Microphone |

During the first use, press and hold 9 to activate the device. On the Home screen, touch any icon to access the corresponding function.

To return to the home screen, press the home screen key . To return to the previous screen, touch the return key . To display the screen of managing active applications, touch the menu key .

Phone Service



© 2003-2017 MLS.

All Rights Reserved.

The MLS and MAIC brand and logos are trademarks of MLS Information Technology, registered in Greece and other countries.

Android is a trademark of Google, Inc.

Hereby the manufacturer MLS Informatics A.E. indicates that the device complies with the essential requirements and other relevant provisions of Directive 1999/5/EK.

A copy of the Declaration of Conformity can be obtained from the web site place of the MLS: <http://www.mlsshop.gr/content/diloseis-symmorfosis>

MLS Innovation Inc. ICT Business Park, 555 35, Thessaloniki, Greece
www.mls.gr, mail@mls.gr

