

## Structure



- |                                 |                                      |
|---------------------------------|--------------------------------------|
| ① Rear camera                   | ⑨ Micro USB port                     |
| ② Flash                         | ⑩ Speaker                            |
| ③ 3.5mm earphones slot          | ⑪ Back to the previous screen        |
| ④ Receiver                      | ⑫ Home screen key                    |
| ⑤ Front camera                  | ⑬ Management key/Active applications |
| ⑥ Increase/ Decrease volume key |                                      |
| ⑦ Activate/ Lock key            |                                      |
| ⑧ Microphone                    |                                      |

When you switch on your phone for the first time, press and hold key 7 to activate the telephone.

At the initial screen, touch any icon to access the relative application.

To move back to the home screen, touch the ○ home screen key. To move back, tap on the back icon ◀. To open the active application management screen, touch the tab □.

## Phone Initialization

For Single SIM Users

In order to take out the back cover of your phone, pull the cap upwards from its niche, as shown in the picture.



## Phone Initialization

For Dual SIM Users

In order to take out the back cover of your phone, pull the cap upwards from its niche, as shown in the picture.



## Insert & Remove SIM and SD cards

To insert SIM and SD cards, place the cards in the corresponding slot, as shown in the picture on the right.

In order to remove the SIM and SD cards, follow the same steps in reverse.



## Insert & Remove SIM and SD cards

To insert SIM and SD cards, place the cards in the corresponding slot, as shown in the picture.

In order to remove the SIM and SD cards, follow the same steps in reverse.



## Main menu

Navigate on the main menu by dragging the screen left and right to switch pages on the main menu. Tap and hold on any icon you want, in order to drag it to the main screen, as a shortcut. To go back to the main screen press the corresponding key.

## Lock & Unlock

In order to lock your device, tap the activation key. In order to unlock your device, tap the activation key. When the lock icon appears on the screen, drag upwards.

## Settings

To access all settings options, touch the top of the touch screen and drag downwards twice. By tapping on the following key  you can access the general settings. On the "Settings" screen, you can personalize your device to suit your needs, by setting its functions accordingly. Networks, WiFi, Bluetooth settings, sounds, appearance, applications, all at the tips of your fingers.

## MAIC (Settings)

You can set the basic functions of your device through MAIC. Specifically, you can activate/ deactivate the Bluetooth, wifi, data use, gps and silent mode by using voice command. Alternatively, you can just say "Settings" and then chose from the settings options.

## Quick Settings

By dragging once the upper end of the screen downwards, the settings options will appear. If you drag it once more, quick settings will appear, as shown below.



**Brightness** Sets the brightness of the screen.



**Wireless networks**-Activate the wifi when you're inside the range of a known wireless network and deactivate it when you're moving away and you want to save battery power.



**Bluetooth** - Allow your device to connect with other devices and Bluetooth accessories to transfer contacts, photos and files or to just use your wireless earphones.



**Automatic Rotation** - It allows the automatic rotation of the screen.



**Screen Transfer** - Transfer the subject screened on your device to another screen.



**Flight Mode**- When you activate Flight Mode, all wireless connectivity options will be deactivated. You can reactivate the Wifi and Bluetooth options through Settings or the quick settings menu.



**Data Connection** - Activate and Deactivate mobile data.




**GPS** - Activate your GPS and your MLS device will give you information regarding your geographical location in any application necessary, such as Talk&Drive.

Drag the notification options once and you can see all your notifications, i.e. Messages, missed calls, e-mails, application updates.

## Home screen

Arrange your folders, your applications and widgets by tapping and holding your finger on any icon and drag it where you wish. Through this process, the home screen of your device will be arranged in a way that best serves your needs.



## Music and Videos

---

Transfer the music you like to your device, download music from the internet and enjoy the high quality sound from your device's speaker or your earphones. A world full of music at the tips of your fingers. A world you can create and enjoy, exactly as you prefer. Watching videos you like is a piece of cake with your MLS device. Furthermore, it offers you video descriptions and information with pictures and playlist texts. Your favorite movies, series or YouTube videos can keep you high quality company, wherever you are.

## Photos and Camera

---

Touch, tap or pinch on the screen of your device to zoom in or zoom out on a picture. Furthermore, there's automatic rotation between horizontal and vertical function for picture screening. Your favorite moments are always with you, in the way you want to remember them.

By using zoom or flash, you can take your favorite pictures or videos. Save photos and videos from parties, concerts, vacation or any other images you like in your device's memory and your own, share them with friends through e-mail and MMS.

## Home screen

---

Arrange your folders, your applications and widgets by tapping and holding your finger on any icon and drag it where you wish. Through this process, the home screen of your device will be arranged in a way that best serves your needs.

## Radio

---

Plug in your earphones and listen to the radio station of your choice, save your favorite stations for easy access every time you use the application. With just one click, your favorite radio station is there to keep you company and bring music to your moments.

## Internet

---

By choosing the internet browser application  on the lower right side of the home screen and by inputting the website you would like to visit, you can easily surf the web and immediately navigate on any web page you like. Furthermore, you can touch the screen to zoom in/ zoom out and you can chose through the "Menu" to open more windows for simultaneous navigation in different internet web pages. Discover the easiest and fastest Internet trip ever. στο πιο εύκολο και γρήγορο ταξίδι που έγινε ποτέ.



**Wireless networks** - Activate the wifi when you're inside the range of a known wireless network and deactivate it when you're moving away and you want to save battery power.



**Bluetooth** - Allow your device to connect with other devices and Bluetooth accessories to transfer contacts, photos and files or to just use your wireless earphones.



**Automatic Rotation** - It allows the automatic rotation of the screen.



**Screen Transfer** - Transfer the subject screened on your device to another screen.



**Data Connection** - Activate and Deactivate mobile data.



**Flight Mode** - When you activate Flight Mode, all wireless connectivity options will be deactivated. You can reactivate the Wifi and Bluetooth options through Settings or the quick settings menu.




**GPS** - Activate your GPS and your MLS device will give you information regarding your geographical location in any application necessary, such as Talk&Drive.

Drag the notification options once and you can see all your notifications, i.e. Messages, missed calls, e-mails, application updates.

## Home screen

Arrange your folders, your applications and widgets by tapping and holding your finger on any icon and drag it where you wish. Through this process, the home screen of your device will be arranged in a way that best serves your needs.



## Internet

By choosing the internet browser application  on the lower right side of the home screen and by inputting the website you would like to visit, you can easily surf the web and immediately navigate on any web page you like. Furthermore, you can touch the screen to zoom in/ zoom out and you can chose through the "Menu" to open more windows for simultaneous navigation in different internet web pages. Discover the easiest and fastest Internet trip ever.

## Mouisc and Video

Transfer the music you like to your device, download music from the internet and enjoy the high quality sound from your device's speaker or your earphones. A world full of music at the tips of your fingers. A world you can create and enjoy, exactly as you prefer. Watching videos you like is a piece of cake with your MLS device. Furthermore, it offers you video descriptions and information with pictures and playlist texts. Your favorite movies, series or YouTube videos can keep you high quality company, wherever you are.

## Photos and Camera

Touch, tap or pinch on the screen of your device to zoom in or zoom out on a picture. Furthermore, there's automatic rotation between horizontal and vertical function for picture screening. Your favorite moments are always with you, in the way you want to remember them. You can use the Camera application to take pictures or videos, with or without zoom or flash, depending on the case. Save party moments, concerts, vacation or any other pictures or videos you like in your device's memory or its external card (if there is one). Share them with your friends or your contacts, through e-mail, MMS or any other application used for multimedia data sharing.

## Radio

Plug in your earphones and listen to the radio station of your choice, save your favorite stations for easy access every time you use the application. With just one click, your favorite radio station is there to keep you company and bring music to your moments.

## MLS Offices

### Customer Service Department of Attica

📍 40, Digeni Akrita str. & Argyroupoleos, T.K. 16451, Argyroupoli  
Monday to Friday 9:00am-5:00pm

### Customer Service Department of Thessaloniki

📍 VEPE TECHNOPSIS, 555 35, Pylaia, Thessaloniki  
Monday to Friday 9:00am-5:00pm

## MLS Updater

For your accommodation, MLS has created the MLS Updater. MLS Updater is a tool that allows you to do the following to your Android device:

- ▶ Update the latest MLS Services versions.
- ▶ Update your maps
- ▶ Update your ROM software by fixing possible problems.
- ▶ Keep yourself updated on important subjects regarding
- ▶ MLS products and services

MLS Updater is pre-installed in your device. For better support, MLS suggests that you regularly update it to its latest version through Google Play Store. In that way, you'll be continuously updated and receive support for technical issues.

Note: MLS Updater is exclusively addressed to MLS smartphone and tablet users.

MLS Destinator users can update their maps to their latest version via our website [www.mls.gr](http://www.mls.gr). Register on our members tab and download the new maps for free via The process is simple and does not require advanced computer knowledge.

## Useful Tips

- ▶ To ensure the optimum function of your device, we recommend that you reboot it at regular intervals.
- ▶ Keep a backup of your personal data (contacts, photos, music etc.) In that way, you'll make sure that your personal data will be safe in case of loss or malfunction of your device. In case you address the MLS Technical Department, please make sure that you have kept a backup of your data, because we might have to, for example, switch your device's motherboard during the repair, meaning that all your data will be lost.
- ▶ It is recommended that you do not use accessories manufactured by third parties (chargers, wires, batteries), because they might lead to malfunctions or even damages to your device.
- ▶ In case your device won't charge, make sure that you're using the original charger of the product and that the cable has been properly plugged in. Connect your device to the USB port of your computer and see if it works.
- ▶ In case your Android device freezes, take out the battery, press the reset button or keep the on/off button pressed continuously for 30-40 secs.
- ▶ If you happen to notice that your device keeps malfunctioning after a ROM update, we recommend you to try resetting your device.
- ▶ In order for you to discover and use the 100% of the capabilities of an Android device, you'll need to add a Google account.

In case you have any questions, call 2310 989838 and visit our website [www.mls.gr](http://www.mls.gr). There, you'll find all our manuals and the characteristics of MLS devices, as well as all the frequently asked questions.

The information included in the manual that you're holding are indicative. Real time functions vary, depending on the operating system edition of the device.

## Telephone Assistance



© 2003-2018 MLS.

All rights reserved.

The business names and logos MLS, MAIC and iQTalk Color 5,5 4G are trademarks owned by MLS Innovation, registered in Greece and in other countries.

Android is a trademark owned by Google Inc.

With the present, the manufacturer MLS Informatics declares that the device is in compliance with all essential demand and other relative clauses of the directive 1999/5/EC.

A copy of the Compliance Declaration can be found at the MLS website: <http://www.mlsshop.gr/content/diloseis-symmorfosis>



CE 0700